Conversion Table - dBuV to uV/mV

The formula used:

signal level [dBuV] = 20log (U/1uV) ("u" stands for Greek letter denoting a factor of 10^{-6} - one millionth)

Signal level [dBuV]	Voltage [uV]	 Signal level [dBuV]	Voltage [mV]
0	1	60	1
1	1.12	61	1.12
2	1.25	62	1.25
3	1.41	63	1.41
4	1.59	64	1.59
5	1.78	65	1.78
6	2	66	2
7	2.24	67	2.24
8	2.51	68	2.51
9	2.82	69	2.82
10	3.16	70	3.16
11	3.55	71	3.55
12	4	72	4
13	4.47	73	4.47
14	5.01	74	5.01
15	5.62	75	5.62
16	6.31	76	6.31
17	7.06	77	7.06
18	8	78	8
19	8.91	79	8.91
20	10	80	10
21	11.2	81	11.2
22	12.5	82	12.5
23	14.1	83	14.1
24	15.9	84	15.9
25	17.8	85	17.8
26	20	86	20
27	22.4	87	22.4
28	25.1	88	25.1
29	28.2	89	28.2
30	31.6	90	31.6
31	35.5	91	35.5
32	40	92	40
33	44.7	93	44.7
34	50.1	94	50.1
35	56.2	95	56.2

.03.2021		CONVENSION TABLE - abay to avinty	
36	63.1	96	63.1
37	70.8	97	70.8
38	80	98	80
39	89.1	99	89.1
40	100	100	100
41	112	101	112
42	125	102	125
43	141	103	141
44	159	104	159
45	178	105	178
46	200	106	200
47	224	107	224
48	251	108	251
49	282	109	282
50	316	110	316
51	355	111	355
52	400	112	400
53	447	113	447
54	501	114	501
55	562	115	562
56	631	116	631
57	706	117	706
58	800	118	800
59	891	119	891
60	1000	120	1000